

## INSTALLING SHEET FOR BEECH WALL BARS, code 216 F

1. Place the metal corners with the long wing on the inside of the wallbars. They also can be fixed outside of the wallbars.



2. Enter the bolt from inside to the outside in the holes made and fix the corners on the outside with the help nut.

3. Place the wallbars in the desired position and mark on the wall the place where want to make the wall drilling, make the holes, insert



4. **Important:**

Check if the wallbar is well fixed on the wall!

For further information please visit: [www.artimexsport.com](http://www.artimexsport.com)