

ANSSEMBLY INSTRUCTIONS WOODEN WALL BARS

1-2: Place the wood spacers in the indicated position on the back of the wallbars. Fix the spacers on the sides of the wallbars by screwing the bolts through the holes of the spacers.

3-4: Place the metal corners with the long wing on the inside of the wallbars. They also can be fixed on the outside of the wallbars. Enter the bolt from inside to the outside in the holes made and fix the corners on the outside with the help nut.

5-6-7-8: Place the wallbars in the desired position and mark on the wall the place where want to make the wall drilling, make the holes, insert dowels, fix the bolt in the dowel and screw.

Important: Important: Check if the wallbar is well fixed on the wall.

